



COMMERCIAL REFRIGERATOR

HRE-188SC-S
HRE-188SC-P

PARTS LIST

[HHK] [HPH]

S189-C100,S189-C300

Q-1 NOV. 2025

S189-5836(1125)

Product Code		Spec	
S189-C100	For HHK	HRE-188SC-S	50Hz
S189-C300	For HPH	HRE-188SC-P	60Hz

AUXILIARY CODE

U - 1

The auxiliary code is the first two characters in the serial number. The first character indicates the production year. Years progress or regress in alphabetical order. The series of letters and skipped letters depend on UL listing, production, and model. See the auxiliary code(s) and corresponding year(s) on the front cover.


The second character indicates significant part changes within the same year. Base is "1" and this number advances for each change. If there is no significant part change at the turn of the year, this number starts from "0."

MARKS LOCATED UNDER THE AUXILIARY CODE

- = Part deleted.

FASTENER PART NUMBER


SCREWS





*1 Material

F: Steel
S: Austenitic stainless steel
M: Martensitic stainless steel
B: Copper alloy
P: Polycarbonate
N: Polyamide
V: PVC
A: ABS
X: Polyacetal
L: Aluminum

NUTS & WASHERS









MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: A. REFRIGERATOR ASSY					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
B	REFRIGERATION ASSY	(S-35667)	1C0974A02	1			
C	RELAY BOX ASSY	(S-35550)	2C1429A01	1			
D	AIR DUCT ASSY	(S-20038)	252535A01	1			
E	DOOR(R)-UP,ASSY	(S-35534)	2C1416A01	2			
F	DOOR(R)-LO,ASSY	(S-24689)	261787A01	2			
G	DOOR(L)-UP,ASSY	(S-35535)	2C1417A01	1			
H	DOOR(L)-LO,ASSY	(S-24691)	261789A01	1			
J	FRONT PANEL ASSY	(S-35544)	2C1426A04	1			
M	LABEL LOCATION		-	1			
N	ACCESSORIES		-	1			
1	BODY		1C0907G03	1			
2	GRIP(A)		260268M01	2			
3	GRIP(B)		260269M01	2			
4	FLANGE BOLT (S-TITE)		P02005-01	34			
5	FLANGE BOLT (S-TITE)		445994-05	35			
6	TRUSS HEAD TAPPING SCREW (S-TITE)		FTS0412M0	2			
			FTS0412M0	3			
7	DOOR HINGE (R) , LO		375316G01	2			
8	DOOR HINGE (R) , CT		375317G01	2			
9	DOOR HINGE (R) , UP		375315G01	2			
10	HINGE COLLAR - HINGE		339948-01	6			
11	HOLE PLUG		463980-01	7			
12	POWER SUPPLY CORD -HS	S189-C100	474677G01	1			
	POWER SUPPLY CORD - PHILIPPINES	S189-C300	4C1024G01	1			
13	NOISE FILTER		3C1540G01	1			
14	PAN HEAD SCREW SW		FSK0308S0	30			
15	TRUSS HEAD SCREW		FST0412S0	1			
16	SPRING WASHER		FWSP04S0	1			
17	SIDE PANEL (R)		382770M02	1			
18	SIDE PANEL (L)		382771M02	1			
19	S-TITE TRUSS HEAD SCREW		FTS0406M0	2			
20	BAG		485815P01	2			
21	WIRE RETAINER		427902-03	2			
22	BRACKET - SHROUD		481806M02	1			

MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: A. REFRIGERATOR ASSY					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
23	BRACKET - SHROUD (R)		4C0723M01	1			
24	SHROUD (R)		3C1414M01	1			
25	SHROUD - RELAY BOX		2C1753M01	1			
26	REAR COVER		270021M01	1			
27	BUSHING		428394-03	1			
28	TOP COVER		2C1656M01	1			
29	WIRING LABEL		3C1560L01	1			
30	LABEL-ENERGY		1C1058L04	-			
31	DOOR HINGE (L) , LO		375319G01	1			
32	DOOR HINGE (L) , CT		375320G01	1			
33	DOOR HINGE (L) , UP		375318G01	1			
34	SHROUD - HARNESS		2C1752M01	1			
35	SHROUD (L)		3C1474M01	1			
36	BRACKET		484645M01	1			
37	WIRE RETAINER		427902-05	5			
38	BRACKET - LEAD SWITCH		3C1273M01	3			
39	HEX HEAD BOLT SW		FBK0408S0	6			
40	HARNESS - REED SWITCH		3C1580G01	1			
41	COVER - REED SWITCH		4C0837M01	3			
42	TRUSS HEAD SCREW		FST0408S0	6			
43	COVER		386702M01	1			
44	GROMMET		410666-05	1			
45	T2 TRUSS HEAD SCREW		FT20408M0	2			




MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: B. REFRIGERATION ASSY (S-35667)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
K	FAN MOTOR AY		2C0972A02	1			
L	INVERTER BOX AY		2C0973A02	1			
1	BASE		1C0922G01	1			
2	COMPRESSOR		P06828-02	1			
3	RUBBER GROMMET		P07608-01	4			
4	TERMINAL COVER		P06254-01	1			
5	SCREW		P06255-01	1			
6	BOLT		C05825-01	3			
7	CONDENSER		P00167-01	1			
8	COVER - CONDENSER		3C1349M01	1			
9	FLANGE BOLT (S-TITE)		P02005-01	8			
10	TAPPING SCREW - HEX		456789-01	4			
11	TRUSS HEAD SCREW		FST0408S0	4			
12	THERMISTOR		469096-01	1			
13	THERMISTOR - HOLDER		458132-01	1			
14	EVAPORATOR		P00165-01	1			
15	TRUSS HEAD TAPPING SCREW T2		FT20412M0	4			
16	DEFROST HEATER		P02930-01	1			
17	FUSE		P01103-01	1			
18	SUPPORT (G) - HEATER		369622G01	1			
19	HEAT EXCHANGER		2C1609G02	1			
20	COPPER TUBE (A) - H		3C1350M01	1			
21	COPPER TUBE (B) - (H)		4C0712G01	1			
22	DRIER		P00026-01	1			
23	CLAMP		427902-02	1			
24	COPPER TUBE - CAPILLARY		4C0740M01	1			
	COPPER TUBE (B) - CAPILLARY		446047-02	1			
25	Insulation Tube (Armaflex)		H91022070	2			
26	HANDLE		3C1707M01	2			
27	BRACKET - FUSE		469036-01	1			
28	CLAMP		427902-04	1			
			427902-04	3			
29	WIRE RETAINER		427902-05	8			
30	THERMISTOR BRACKET		456019-02	1			


MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: B. REFRIGERATION ASSY (S-35667)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
31	THERMISTOR HOLDER		320418-01	1			
32	AIR FILTER		385765G01	1			
33	COPPER TUBE L		3C1193G01	1			
34	TRUSS HEAD SCREW		FST0412S0	1			
35	SPRING WASHER		FWSP04S0	1			
36	FLANGE BOLT (S-TITE)		445994-05	2			
37	T2 TRUSS HEAD SCREW		FT20408M0	3			
38	NYLON TIE		7920-0010	4			
39	NYLON TIE		7920-0011	2			




MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: C. RELAY BOX ASSY (S-35550)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	RELAY BOX (A)		3C1188M01	1			
2	COVER - RELAY BOX		3C1189M01	1			
3	POWER RELAY		430173-05	1			
4	T2(S) FLANGED PAN HEAD SCREW		431415-01	2			
5	BUSH		4C0219R01	1			
6	CONTROLLER BOARD		P05426-04	1			
7	BOARD SUPPORT		P01770-01	4			
8	SWITCHING REGULATOR		C05928-01	1			
9	BOARD SUPPORT		460857-02	4			
10	PROTECTOR		440972-01	1			
11	TRUSS HEAD SCREW		FST0408S0	2			
12	SPRING WASHER		FWSP04S0	2			
13	FLANGE BOLT (S-TITE)		445994-05	3			




MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: D. AIR DUCT ASSY (S-20038)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	AIR DUCT		118517G01	1			
2	FAN MOTOR		C06057-01	2			
3	PAN HEAD MACHINE SCREW (SPRING WASHER AND FLAT WASHER)		FSK0430S0	4			
4	FAN COVER		242785-01	2			
5	TRUSS HEAD SCREW		FST0412S0	2			
6	CLAMP		427902-04	1			
7	GASKET - DRAIN ELBOW X		469086-01	1			




MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: E. DOOR(R)-UP,ASSY (S-35534)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	DOOR (A) - G		2C1414G01	1			
2	DOOR GASKET - HD		258160G01	1			
3	DOOR STOPPER		454210-01	1			
4	FLAT HEAD TAPPING SCREW (S-TITE)		FTF0512M0	2			
5	HANDLE COVER		127533P01	1			
6	SCREW - BOLT		P02006-01	2			
7	HANDLE BASE		276553P01	1			
8	HOLE PLUG		463980-01	2			
9	MAGNET		436974-01	1			
10	PAN HEAD SCREW SW		FSK0308S0	2			




MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: F. DOOR(R)-LO,ASSY (S-24689)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	DOOR (B) - G		261785G01	1			
2	DOOR GASKET - HD		258160G01	1			
3	DOOR STOPPER		454210-01	1			
4	FLAT HEAD TAPPING SCREW (S-TITE)		FTF0512M0	2			
5	HANDLE COVER		127533P01	1			
6	SCREW - BOLT		P02006-01	2			
7	HANDLE BASE		276553P01	1			
8	HOLE PLUG		463980-01	2			




MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: G. DOOR(L)-UP,ASSY (S-35535)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	DOOR (B) - G		2C1415G01	1			
2	DOOR GASKET - HD		258160G01	1			
3	DOOR STOPPER		454210-01	1			
4	FLAT HEAD TAPPING SCREW (S-TITE)		FTF0512M0	2			
5	HANDLE COVER		127533P01	1			
6	SCREW - BOLT		P02006-01	2			
7	HANDLE BASE		276553P01	1			
8	HOLE PLUG		463980-01	2			
9	MAGNET		436974-01	1			
10	PAN HEAD SCREW SW		FSK0308S0	2			




MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: H. DOOR(L)-LO,ASSY (S-24691)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	DOOR (A) - G		261784G01	1			
2	DOOR GASKET - HD		258160G01	1			
3	DOOR STOPPER		454210-01	1			
4	FLAT HEAD TAPPING SCREW (S-TITE)		FTF0512M0	2			
5	HANDLE COVER		127533P01	1			
6	SCREW - BOLT		P02006-01	2			
7	HANDLE BASE		276553P01	1			
8	HOLE PLUG		463980-01	2			





MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: J.FRONT PANEL ASSY (S-35544)					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	FRONT PANEL(G)		2C1425G04	1			
2	CORNER - FRONT PANEL(R)		260090P03	1			
3	CORNER - FRONT PANEL(L)		260091P03	1			
4	SPACER		451658-05	4			
5	BRACKET - COVER		3C1184M01	1			
6	NUT		FNH103F0	4			
7	COVER - BOARD		3C1185M01	1			
8	TRUSS HEAD SCREW		FST0408S0	4			
9	BUSHING		428394-02	1			
10	OPERATION LABEL		3J0480L01	1			
11	OPERATION BOARD	OPERATION BOARD ASSY (3C0704A01)	P06503-01	1			
12	LABEL - 7 SEGMENT	OPERATION BOARD ASSY (3C0704A01)	489771L01	1			











MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: K. FAN MOTOR AY					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	SHROUD		131633P01	1			
2	FAN MOTOR C		P07098-01	1			
3	HEX HEAD BOLT SW		FBK0416S0	3			
4	NUT		FNH104S0	3			
5	FAN		465748-01	1			
6	NUT (LEFT HAND THREAD)		FN1L06S0	1			



MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: L. INVERTER BOX AY					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	BRACKET - INVERTER		3C0832M01	1			
2	T2 TRUSS HEAD SCREW		FT20408M0	2			
3	T2(S) FLANGED PAN HEAD SCREW		431415-01	2			
4	SPRING WASHER		FWSP04S0	1			
5	TRUSS HEAD SCREW		FST0408S0	1			
6	INVERTER	INVERTER (P06831A01)	P06831-01	1			
7	INDUCTOR	INVERTER (P06831A01)	P06832-01	1			



MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: M. LABEL LOCATION					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	CHARACTER LABEL - PENGUIN		475552L02	1			
2	LABEL - FAN COVER		472775L01	1			
3	MAINTENANCE LABEL		473556L01	1			
4	LABEL - ADVISORY		399626L01	1			
5	CAUTION LABEL - FIRE A		3J0417L01	1			
6	CAUTION LABEL - FIRE B		3J0418L01	1			
7	LABEL - HACCP		476519L01	1			



MODEL:	HRE-188SC-S,HRE-188SC-P	TITLE: N. ACCESSORIES					
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER	REQ'D NUMBER			
				Q-1			
1	INSTRUCTION MANUAL		L1S186***	1			
2	CLIP-SHELF		428957-01	48			
3	SHELF - 127HD	S189-C100	383027G01	8			
		S189-C300	3C1968G01	8			
4	LEG		P05012-01	6			
5	FLEXIBLE HOSE - TRAP	DRAIN HOSE ASSY (471190A02)	P00114-01	1			
6	BAND - DRAIN HOSE(21)	DRAIN HOSE ASSY (471190A02)	472603M01	1			
7	SHELF - 187HD	S189-C100	3C0119G01	4			
		S189-C300	376163G01	4			
8	INSTRUCTION SHEET - EVAPORATING PAN		273007L01	1			
9	EVAPORATING PAN SET	(S-29687)	272922A01	1			