



UNDER COUNTER REFRIGERATOR

RT-98MC-P

PARTS LIST

[HPH]

T434-C300

Q-2 OCT. 2024

T434-5793 (0526)

Product Code Spec

RT-98MC-P

T434-C300	For HPH ; Standard
------------------	--------------------

AUXILIARY CODE


U - 1

The auxiliary code is the first two characters in the serial number. The first character indicates the production year. Years progress or regress in alphabetical order. The series of letters and skipped letters depend on UL listing, production, and model. See the auxiliary code(s) and corresponding year(s) on the front cover.

The second character indicates significant part changes within the same year. Base is "1" and this number advances for each change. If there is no significant part change at the turn of the year, this number starts from "0."

FASTENER PART NUMBER


SCREWS



*1


- F: Steel
- S: Austenitic stainless steel
- M: Martensitic stainless steel
- B: Copper alloy
- P: Polycarbonate
- N: Polyamide
- V: PVC
- A: ABS
- X: Polyacetal
- L: Aluminum

NUTS & WASHERS




*2

- First letter
- S: Machine screw
- T: Tapping screw
- M: Wood screw
- B: Bolt
- W: Washer
- N: Nut




MODEL: RT-98MC-P**TITLE: A. REFRIGERATOR ASSY**

INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER			
				Q-2 and later		
B	BODY AY		1C0152A02	1		
C	REFRIGERATION UNIT		1C1171A01	1		
D	FRONT PANEL AY		3C1100A02	1		
E	CONTROL BOX AY		2C1283A06	1		
L	LABEL LOCATION		1C0775107	1		
M	ACCESSORIES		A03627055	1		
1	TOP PANEL		2C1543M08	1		
2	T2 TRUSS HEAD SCREW		FT20408M0	2		
3	TRUSS HEAD TAPPING SCREW T1		FT10412M0	11		
4	DUCT		1R2914P01	1		
5	DUCT B		3S3562G02	1		
6	POWER SUPPLY CORD - ASSY	(S-25404)	3S3939G01	1		
7	BUSHING		450414-01	1		
8	SPRING WASHER		FWSP04S0	3		
9	TRUSS HEAD SCREW		FST0408S0	3		
10	INSULATION		4R5835Z01	2		
11	AIR FILTER		390723G01	1		
12	THUMBSCREW		428833-01	1		
13	COVER - CONTROL BOX		4C0293P01	1		



MODEL: RT-98MC-P**TITLE: B. BODY AY**


INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
F	DOOR L,AY		2C1442A01	1			
1	BODY		1C1293G01	1			
2	DOOR HINGE (L) , LO		375319G01	1			
3	FLANGE BOLT (S-TITE)		P02005-01	4			
4	DOOR HINGE (L) , UP		375318G01	1			
5	HINGE COLLAR - HINGE		339948-01	1			
6	BASE		389444G01	1			
7	FLANGE BOLT (S-TITE)		FTQ0512F0	2			
8	BRACKET - TOP PANEL		2R5585M02	1			
9	FRAME - UNIT		3S2838M01	1			
10	LOUVER - UNIT		389439M01	1			
11	T2 TRUSS HEAD SCREW		FT20408M0	6			
12	PVC HOSE		HA1821380	1			
13	CLAMP		463936-01	1			
14	SIDE PANEL - UNIT		2R5741M02	1			
15	BRACKET B - TOP PANEL		2R5881M02	1			



MODEL: RT-98MC-P**TITLE: C. REFRIGERATION UNIT**


INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
G	FAN MOTOR AY		3S0697A02	1			
1	DRAIN PAN		280721P01	1			
2	TRUSS HEAD SCREW		FST0512S0	4			
3	COMPRESSOR		P07568-01	1			
4	GROMMET		450897-01	4			
5	BOLT		C05825-01	2			
6	WIRE CONDENSER		P05095-01	1			
7	T2 TRUSS HEAD SCREW		FT20408M0	10			
8	SHROUD-TOP		485253M01	1			
9	HEX HEAD BOLT (SPRING ASHER AND FLAT WASHER)		FBK0510S0	2			
10	EVAPORATOR		C07252-01	1			
11	FAN MOTOR		C07478-01	1			
12	EVAP COVER		2C1875M01	1			
13	T2 TRUSS HEAD SCREW		FT20512S0	4			
14	INSULATION TUBE		H71020260	2			
15	HEAT EXCHANGER		2C2223G01	1			
16	DRIER		C06620-01	1			
17	PIPE A		485255M01	1			
18	PIPE-DISCHARGE		3C1971G01	1			
19	COPPER TUBE (L)		3C1972G01	1			
20	COVER - HEATER		2C1280M01	1			
21	HEATER-GLASS TUBE		C06573-01	2			
22	HEATER BRACKET		3S3049M01	1			
23	FUSE		P04976-01	1			
24	CLIP-FUSE		4R2937-01	2			
25	BRACKET - DRIER		4R5943M01	1			
26	TERMISTOR	白 除霜用 1.5M	C06414-01	1			
27	TERMISTOR	黒 庫内用 1.5M	C06414-02	1			

MODEL: RT-98MC-P				TITLE: C. REFRIGERATION UNIT			
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
28	TERMISTOR	灰 凝縮器用 1.5M	C06414-03	1			
29	PIPE A - EVAPORATOR		4C0573M01	1			
400	STARTING RELAY		P07541-01	1			
401	START CAPACITOR		P07566-01	1			
402	COVER + CLAMP + SCREWS		P07061-01	1			
403	BOLT JOINT FOR ONE COMP		P07833-01	1			




MODEL: RT-98MC-P**TITLE: D. FRONT PANEL AY**

INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
1	FRONT PANEL		2C1282G01	1			
2	INSTRUCTION LABEL		391442L01	-			
3	HINGE B		4R2858-01	2			
4	RIVET		7170-0201	4			
5	PLASTI FOOT		456673-01	1			
6	SUPPORT - MAGNET		484969M01	1			
7	MAGNET CATCH		4R2838-01	1			
8	FRONT PANEL LABEL		4C0554L01	1			
9	CONTROLLER DISPLAY		C06539-01	1			
10	PL LABEL-AIR FILTER		373397L01	1			




MODEL: RT-98MC-P**TITLE: E. CONTROL BOX AY**




INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
1	CONTROL BOX B		2C1284M01	1			
2	CONTROL BOX A		2C1285M01	1			
3	PROTECTOR		440972-01	1			
4	CONTROLLER		C06540-01	1			
5	HARNESS - CONTROLLER		C06580-01	1			
6	GROMMET		4H2568-02	2			
7	HARNESS - CONTROL BOX AY		3C1462G06	1			
8	PAN HEAD SCREW SW		FSK0308S0	2			





MODEL: RT-98MC-P				TITLE: F. DOOR L, AY			
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
1	DOOR - INSULATION		2C1441G01	1			
2	DOOR GASKET		2R5297G04	1			
3	DOOR STOPPER		454210-01	1			
4	FLAT HEAD TAPPING SCREW (S-TITE)		FTF0512M0	2			
5	HOLE PLUG		463980-01	2			



MODEL: RT-98MC-P				TITLE: G. FAN MOTOR AY			
INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
1	BRACKET - FM		4R4476M01	1			
2	FAN BLADE		P00006-01	1			
3	FLAT WASHER		FWPL04S0	2			
4	SPRING WASHER		FWSP04S0	2			
5	NUT		FNH104S0	2			
6	FAN MOTOR		4R5617G02	1			








NAME PLATE



MODEL: RT-98MC-P**TITLE: L. LABEL LOCATION**

INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
1	CHARACTER LABEL - PENGUIN		475552L01	1			
2	PL LABEL-ELECTRIC SHOCK		474438L01	1			
3	WIRING LABEL		3C1977L01	1			
4	LABEL - ENERGY		1C0777L05	-			
5	CAUTION LABEL/CYCLOPENTANE		481523L01	-			
6	LABEL-SDoC		486283L01	-			
7	INSTRUCTION LABEL		375667L01	1			
8	LABEL - HACCP		476519L01	-			
9	LABEL - ADVISORY		399626L01	1			
10	CAUTION LABEL - FIRE A		3J0417L01	1			
11	CAUTION LABEL - FIRE B		3J0418L01	1			



MODEL: RT-98MC-PTITLE: **M.ACCESSORIES**

INDEX NO.	DESCRIPTION	MATERIAL OR MODEL NUMBER	PART NUMBER				
				Q-2 and later			
1	INSTRUCTIONS MANUAL		L1T430***	1			
2	SHELF H		3S3016G08	2			
3	CLIP-SHELF		428957-01	8			
4	PROTECTOR		4R5783P01	2			
5	LEG		P05012-01	5			